

Article

# Renewable Substitutability Index: Maximizing Renewable Resource Use in Buildings

Ravi S. Srinivasan <sup>1,\*</sup>, Daniel E. Campbell <sup>2,†</sup> and Wei Wang <sup>1,†</sup>

<sup>1</sup> M.E. Rinker, Sr. School of Construction Management, University of Florida, Gainesville, FL 32611, USA; E-Mail: [swingingbach@gmail.com](mailto:swingingbach@gmail.com)

<sup>2</sup> U.S. Environmental Protection Agency, Office of Research and Development, National Health and Environmental Effects Research Laboratory, Atlantic Ecology Division, Narragansett, RI 02882, USA; E-Mail: [campbell.dan@epa.gov](mailto:campbell.dan@epa.gov)

<sup>†</sup> These authors contributed equally to this work.

\* Author to whom correspondence should be addressed; E-Mail: [sravi@ufl.edu](mailto:sravi@ufl.edu); Tel.: +1-352-273-1164; Fax: +1-352-392-9606.

Academic Editor: Elma Durmisevic

Received: 8 April 2015 / Accepted: 18 May 2015 / Published: 22 May 2015

---

**Abstract:** In order to achieve a material and energy balance in buildings that is sustainable in the long run, there is an urgent need to assess the renewable and non-renewable resources used in the manufacturing process and to progressively replace non-renewable resources with renewables. Such progressive disinvestment in the non-renewable resources that may be substituted with renewable resources is referred to as “Renewable Substitutability” and if implemented, this process will lead to a paradigm shift in the way building materials are manufactured. This paper discusses the development of a Renewable Substitutability Index (RSI) that is designed to maximize the use of renewable resources in a building and quantifies the substitution process using solar energy (*i.e.*, the solar equivalent joules required for any item). The RSI of a building or a building component, *i.e.*, floor or wall systems, *etc.*, is the ratio of the renewable resources used during construction, including replacement and maintenance, to the building’s maximum renewable energy potential. RSI values range between 0 and 1.0. A higher RSI achieves a low-energy building strategy promoting a higher order of sustainability by optimizing the use of renewables over a building’s lifetime from formation-extraction-manufacturing to maintenance, operation, demolition, and recycle.

**Keywords:** Renewable Substitutability Index (RSI); emergy analysis; Renewable Emergy Balance; environmental building design

---

## 1. Introduction

Environmental evaluation of buildings has played an essential role in conserving resource use and improving overall performance. Approaches such as Life Cycle Assessment (LCA) and other ecological accounting models offer environmental decision-making solutions. While on one hand, LCA methods explicitly include manufacturing and maintenance energies or costs, they exclude much of the environmental work provided by the biosphere in the formation and concentration of resources, particularly raw materials used in the manufacture of building materials. With respect to inventory data and aggregation methods, LCA primarily focuses on emissions, and direct and indirect consumption of resources through every stage of a product's life cycle. This involves a cradle-to-grave approach to evaluating the product or process, since its environmental impact is assessed from the point of obtaining the raw materials for product development through production, distribution, and its final disposal or recycling [1,2].

In the building sector, embodied energy of the building materials and energy consumption and the associated emissions over the period of use were evaluated using the LCA method [3]. While almost all of the embodied energy is accumulated during the construction phase of the building, energy used for operating the building, *i.e.*, electricity, chilled water, water, steam, wastewater treatment, *etc.*, constitutes the operational phase of the building. A study by Sartori and Hestnes [4] revealed a linear relation between operating and total energy use across sixty cases in a survey of nine countries. A similar study by Ramesh *et al.* [5] showed that most of the building lifecycle energy is expended during its operational phase. In [6], a methodological approach was proposed to design and evaluate eco-design of buildings. Besides concluding that the operational phase had the highest contribution over the entire lifecycle of the three buildings studied in this paper, Asdrubali *et al.* implemented energy optimizations to reduce operational energy use. Nevertheless, the use of LCA for buildings is not as ubiquitous as in the manufacturing industry. Moreover, issues such as setting system boundaries, procedural responsibility, allocation of inputs used (resource consumption), undesired outputs (emissions), and heavy dependency on data collection expenses and data quality, in some cases impose restrictions on the application of LCA. Besides, most of the ecosystem services that are required for dispersing the emissions and absorbing their impact are not specified in the LCA methods and the links between LCA and natural resource depletion are largely missing [7]. Moreover, lacking a rigorous thermodynamic framework in LCA leads to the incompleteness and inaccuracy of ecosystem analysis and in certain situations may even violate thermodynamic laws [8].

On the other hand, emergy analysis, as an ecological accounting model offers environmental decision-making solutions, which include ecological considerations related to material and energy flows during a building's entire lifetime. Emergy was developed to systematically include all the work required for the preparation and delivery of a resource or service [9]. In emergy analysis, first, a system diagram of the process or system under consideration is constructed. This is followed by

accounting for all inputs and outflows over the lifespan of the material or product, including an inventory of essential processes, storages, and flows [10]. Emergy analysis uses thermodynamic principles and offers a “total environmental analysis” that includes all environmental energies involved in the system under investigation. A few research efforts have focused on assessing built environments using emergy analysis. They are: evaluation of recycling and reuse of building materials [11]; emergy associated with the operation of a building [12]; building manufacturing, maintenance, and development of Em-building indices [13]; emergy evaluation of a green façade [14]; comparison of life cycle methodologies [15]; emergy-energy assessment of buildings [16]. Among these, an energy and emergy based cost-benefit evaluation of building envelopes relative to geographical location and climate [17] focused on the building envelope. Also, an emergy-based method to assess the Renewable Emergy Balance (REB) of a building to guide movement towards the highest order of sustainability was developed and demonstrated using a case study building [18].


The central aspect of a REB is the estimation of the maximum renewable emergy potential of the building. This quantity is a limit, also a moving target, which improves as the technology improves to integrate and/or generate more renewable resources. Moreover, this limit sets a benchmark that is required to achieve a higher level of sustainability in buildings.

In order to strive for material and energy balance in buildings, there is an urgent need to assess the renewable and non-renewable resources used in the manufacturing process and to progressively replace non-renewable resources with renewables. Such progressive disinvestment in non-renewable resources that may be substituted with renewable resources is referred to as Renewable Substitutability (RS), and if implemented, will lead to a paradigm shift in the way building materials are manufactured [18]. For this paper, emergy analysis was chosen as the tool to assess the resources used in building and to develop the Renewable Substitutability Index (RSI). This paper develops a Renewable Substitutability Index to maximize renewable resource use in buildings using emergy analysis as the means of assessment. A case study of an existing building in a university campus setting was used to demonstrate the application of RSI to attain maximum renewable resource investment. This paper is organized as follows: while Section 2 discusses the concept of RSI and its significance, Section 3 uses a case study building in a university campus setting to apply the concept of RSI and to discover how this index can be used for optimal decision-making during material replacement.

## 2. Renewable Substitutability Index (RSI) of a Building

A building is supported by a variety of inputs and outputs, some purchased and others provided free (*i.e.*, without explicit cost) by the environment. Inputs include embodied energies of all kinds and qualities, from the sun shining on the window to the ancient sunlight expended in the formation of the fossil fuels used to prepare the glass through which the sun is shining. By translating all inputs into emergy with a common energy unit, the solar emjoule (sej), meaningful comparisons can be established between renewable and non-renewable resources, and between natural and manmade energies, including refining the assessment of real costs over time. The quasi-sustainability principle as discussed by Holling [19] and Odum [20,21] can be extended to buildings, *i.e.*, related to renew-non-renew substitution [18]. Theoretical possibilities of using non-renewables to take advantage of renewable resources have been discussed by Bastianoni *et al.* [22].

In other words, as emergy is accounted for in a particular system, the renewability and non-renewability of materials are appropriately identified. This, then, is used to develop Renewable Substitutability, followed by, calculating RSI values for decision-making. For example, the electric energy from coal used in a cement manufacturing unit might be replaced with electricity generated from renewable resources such as solar, kinetic energy of wind, water or geothermal heat. Thus, the use of non-renewable resources to improve the system's capacity to exploit renewable resources will aid the development of a quasi-sustainable solution, over the long run. Such non-renewable resources may be replaced with renewable resources progressively. Figure 1 shows a simplified systems diagram.



**Figure 1.** Typical systems diagram of a building. Only building structure was used for this study.


Using emergy analysis and through the identification of the Renewable Substitutability of all non-renewable resources, the emergy content may be split into non-renewables with Renewable Substitutability (RS) and unsubstitutable Non-Renewables (NR), *i.e.*, non-renewable resources that cannot be substituted with renewables using the best available technology. Detailed steps and explanation of developing RS and NR for building materials is discussed in Srinivasan *et al.* [18]; Table A.1 in the paper of Srinivasan *et al.* [18] lists the RS and NR for a subset of building materials. Non-renewable resources with Renewable Substitutability have, at least, a potential to be replaced by Renewables (R) and this should be exploited to attain more sustainable buildings. Thus, the Renewable Substitutability Index in a building's useful life is defined as the ratio of the Renewables used in construction, including replacement and maintenance, to its maximum renewable emergy potential. The maximum renewable potential is sum of R and RS.

$$\text{Renewable Substitutability Index} = \sum R_n (R_n + RS_n)^{-1} \quad (1)$$


where  $R_n$  and  $(R_n + RS_n)$  are the amount of renewable materials used and the maximum renewable potential remaining of  $n$  materials.

A building structure may be described as a collection of element-level (e.g., brick, wood flooring, *etc.*) or component-level (e.g., building envelope, HVAC, *etc.*) parts. RSI values range between 0 and 1.0. Thus, by making progressive improvements, over the useful life of a building, all non-renewable resources with Renewable Substitutability can be replaced by renewables, and the RSI of the building will approach 1.0, at which point it will achieve a Renewable Energy Balance. The central aspect of RSI is that it can be used to evaluate improvement strategies during the operation and maintenance phases of existing structures. RSI can also be used to compare element-level building data such as brick, concrete, steel, aluminum, ceramic, wood, *etc.*

Figure 1 compares element-level data; the  $X$ - and  $Y$ - axes represent Renewables ( $R$ ) and maximum renewable energy potential ( $R + RS$ ) respectively. The highest, or optimal, RSI is achieved if the elemental data falls on the bisector, *i.e.*, when  $R$  equals  $(R + RS)$ , *i.e.*, RSI equals 1.0. For example, in Figure 2 (refer to Section 3 for RSI calculation), concrete (RSI, 0.91) falls closer to the bisector when compared to brick (RSI, 0.89). In other words, concrete has a higher renewable energy potential compared to brick. Similarly, aluminum (RSI, 0.99) has the highest renewable energy potential compared to concrete and brick. A similar analysis can be performed at a component-level, for example, groundwork, building frame, external wrapping (sidewalls and facades), internal walls, pavements and coverings, doors and windows, sheet-metal works, and drainage systems, Figure 3. Compared to other building components, “pavements and coverings” possess high RSI indicating that the element-level materials of the components (*i.e.*, carpet, linoleum, red brick, rubber, enamel and vinyl acrylic latex) hold high renewable energy potential and the most desirable renewable resource recovery rate.



**Figure 2.** Renewable Substitutability Index (RSI): Element-level.



**Figure 3.** RSI: Component-level.

As the RSI of particular element- or component- level data and the associated design decision that affects the building's overall performance tends to move towards 1.0, it significantly reduces the total non-renewable energy use of a building over its entire useful life through progressive disinvestment of all substitutable non-renewable resources in a building, thereby, achieving a low- non-renewable energy building with a more sustainable status. Using this index, improvement strategies for existing buildings can be evaluated from a holistic perspective in order to maximize renewable resource use. The following section discusses a case study of an existing facility in a university campus setting that is used to demonstrate the application of RSI to strive for the maximum renewable resource investment.

### 3. RSI of an Existing Building: Case Study

Completed in January 2003, Rinker Hall is a three-story, 47,300-square-foot building that houses the School of Construction Management at the University of Florida, Figure 4. As the first gold standard LEED™ building in the State of Florida, Rinker Hall sets a high bar for design excellence and it incorporates a range of green building features to provide a productive, healthy environment for students, staff, and faculty [23]. Located on the site of a former parking lot, Rinker Hall includes a mix of classrooms, construction labs, teaching labs, faculty and administrative offices, and student facilities. The building was designed to maximize natural light with lighting controls such as motion detectors and low-flow plumbing fixtures and waterless urinals were installed to promote efficiency of water use. Building materials were reviewed for proximity in manufacturing, sustainable harvesting, renewable-resource content, *i.e.*, by using reused bricks from demolition, recycled cellulose insulation material, local and regional assemblies, certified wood, and renewable flooring material. During the operation phase, the building's energy is supplied by three separate energy sources: electricity, chilled water, and steam.



**Figure 4.** (Left) Exterior view of Rinker Hall; (Right) Typical classroom (Photo credits: Croxton Collaborative Architects).

The facility's Renewable Substitutability was first evaluated by studying the building construction, operation, and maintenance phases. Using this data, RSI values, for both elemental- and component-levels, were calculated. These represented each of the retrofit options. These options were plotted to identify optimal solutions for progressive replacement of non-renewable resources with renewables. Technical documents such as construction plans, finish schedules, and commissioning reports were used to generate an inventory of inputs. The inventory included a list of materials used and their mass. For this paper, a few assumptions were used, namely: (i) land use was assumed to be a renewable resource because the site was previously a parking lot and not virgin land; (ii) demolition, site pavement, and human services were excluded; (iii) for materials whose specific emergy values were unavailable, RS was assumed to be 0 (zero), *i.e.*, NR is 1.0; (iv) for materials whose total emergy was unavailable, R was assumed to be 0 (zero) such that the total emergy is  $(RS + NR)$ ; and (v) the RS of operational energy is assumed as 10.6% based on DOE (2010) data, *i.e.*, total electricity generation in the United States included 10.6% renewable generation.

### 3.1. RSI Assessment Methodology

The RSI assessment methodology is comprised of four steps. While the first three steps estimate the emergy content during the building's manufacturing, operation, and maintenance phases, the final step calculates the RSI based on the data from the previous steps. The resultant RSI values can be used to evaluate improvement strategies from a holistic perspective in order to maximize renewable resource content of the existing facility.

#### 3.1.1. Step 1: Emergy Analysis of the Building Manufacturing Process

In this first step, the emergy content of the building materials used during the construction process were quantified. Material emergy is the product of the material quantity derived from contract documents (mass) and specific emergy (sej/kg). In order to identify the Renewable Substitutability portions of materials, the specific emergy was split into three portions namely R, RS, and NR. For this study, the materials were aggregated into ten major categories and each category was further separated into various units for clarity, Table 1. In the case of Rinker Hall building, future replacement and

maintenance efforts may be targeted based on the percentage of Renewable Substitutability of the components. For example, the roofs have 71.1% of RS potential.

**Table 1.** Energy analysis of building manufacturing (RS—Renewable Substitutability; NR—Non Renewables; R—Renewables; El—Elemental; Cp—Component).

Item	Specification	Unit	Specific Energy (sej/kg)				RSI		% of RS
			RS	NR	Total (R + RS + NR)	R	R/(R + RS)		
							El.	Cp.	
Solar irradiation	Irradiation on building yard	J	0	0	1.00	1.00	1.00	1.00	0.00
Land use (soil erosion)	Soil Organic matter (3% of 1 m depth vol.)	J	$1.24 \times 10^5$	0	$1.24 \times 10^5$	0	0	0	1.91
Groundwork								0.84	0.50
Foundation	Concrete	kg	$3.47 \times 10^{10}$	$1.41 \times 10^{12}$	$1.81 \times 10^{12}$	$3.65 \times 10^{11}$	0.91		
Footing	Steel	kg	$1.17 \times 10^{12}$	$4.18 \times 10^{12}$	$6.97 \times 10^{12}$	$1.62 \times 10^{12}$	0.58		
Lean concrete	Concrete	kg	$3.47 \times 10^{10}$	$1.41 \times 10^{12}$	$1.81 \times 10^{12}$	$3.65 \times 10^{11}$	0.91		
Lean concrete	Steel	kg	$1.17 \times 10^{12}$	$4.18 \times 10^{12}$	$6.97 \times 10^{12}$	$1.62 \times 10^{12}$	0.58		
Building frame								0.84	0.68
Bearing wall	Concrete	kg	$3.47 \times 10^{10}$	$1.41 \times 10^{12}$	$1.81 \times 10^{12}$	$3.65 \times 10^{11}$	0.91		
Beams and columns	Concrete	kg	$3.47 \times 10^{10}$	$1.41 \times 10^{12}$	$1.81 \times 10^{12}$	$3.65 \times 10^{11}$	0.91		
Exterior structure framing	Steel	kg	$1.17 \times 10^{12}$	$4.18 \times 10^{12}$	$6.97 \times 10^{12}$	$1.62 \times 10^{12}$	0.58		
Gypsum dry construction	Steel	kg	$1.17 \times 10^{12}$	$4.18 \times 10^{12}$	$6.97 \times 10^{12}$	$1.62 \times 10^{12}$	0.58		
Framing									
Overhangs	Concrete	kg	$3.47 \times 10^{10}$	$1.41 \times 10^{12}$	$1.81 \times 10^{12}$	$3.65 \times 10^{11}$	0.91		
Stairs	Concrete	kg	$3.47 \times 10^{10}$	$1.41 \times 10^{12}$	$1.81 \times 10^{12}$	$3.65 \times 10^{11}$	0.91		
Elevator Box	Concrete	kg	$3.47 \times 10^{10}$	$1.41 \times 10^{12}$	$1.81 \times 10^{12}$	$3.65 \times 10^{11}$	0.91		
Elevator Box	Steel	kg	$1.17 \times 10^{12}$	$4.18 \times 10^{12}$	$6.97 \times 10^{12}$	$1.62 \times 10^{12}$	0.58		
External wrapping (side walls + facades)								0.92	0.14
Side wall (16" thick)	CMU	kg	0	1.00	1	0	0		
Side walls thermal insulation	fiberglass	kg	0	1.00	1.00	0	0		
Binder (Side wall)	Mortar	kg	0	1.00	$3.31 \times 10^{12}$	$3.31 \times 10^{12}$	1		
Precast side wall coping	Concrete	kg	$3.47 \times 10^{10}$	$1.41 \times 10^{12}$	$1.81 \times 10^{12}$	$3.65 \times 10^{11}$	0.91		

Table 1. Cont.

Item	Specification	Unit	Specific Emergy (sej/kg)				RSI		% of RS
			RS	NR	Total (R + RS + NR)	R	R/(R + RS)		
							El.	Cp.	
Precast screen wall coping	Concrete	kg	$3.47 \times 10^{10}$	$1.41 \times 10^{12}$	$1.81 \times 10^{12}$	$3.65 \times 10^{11}$	0.91		
Façades (External skin)	CMU	kg	0	1.00	1.00		0		
Façades	Brick	kg	$1.89 \times 10^{11}$	$2.03 \times 10^{12}$	$3.68 \times 10^{12}$	$1.46 \times 10^{12}$	0.89		
Binder	Mortar	kg	0	1.00	$3.31 \times 10^{12}$	$3.31 \times 10^{12}$	1.00		
Thermal insulation	Extruded polystyrene	kg	0	1.00	1.00	0	0		
Thermal insulation	Fiberglass	kg	0	1.00	1.00	0	0		
Filling	Concrete	kg	$3.47 \times 10^{10}$	$1.41 \times 10^{12}$	$1.81 \times 10^{12}$	$3.65 \times 10^{11}$	0.91		
Floors								0.60	23.2
Floor (20 cm thick)	Concrete	kg	$3.47 \times 10^{10}$	$1.41 \times 10^{12}$	$1.81 \times 10^{12}$	$3.65 \times 10^{11}$	0.91		
Floor (3-3/8" & 7 3/8" thick)	Red Brick	kg	$1.89 \times 10^{11}$	$2.03 \times 10^{12}$	$3.68 \times 10^{12}$	$1.46 \times 10^{12}$	0.89		
Insulation	High-density polyethylene	kg	0	1.00	$8.85 \times 10^{12}$	$8.85 \times 10^{12}$	1.00		
Vapor barrier	Concrete	kg	$3.47 \times 10^{10}$	$1.41 \times 10^{12}$	$1.81 \times 10^{12}$	$3.65 \times 10^{11}$	0.91		
Tile	Ceramic	kg	$1.03 \times 10^{12}$	$2.03 \times 10^{12}$	$3.68 \times 10^{12}$	$6.20 \times 10^{11}$	0.38		
Floor deck	Steel	kg	$1.17 \times 10^{12}$	$4.18 \times 10^{12}$	$6.97 \times 10^{12}$	$1.62 \times 10^{12}$	0.58		
Roof								0.58	71.1
Roof	Gypsum	kg	0	1.00	1.00	0	0		
Roof (Shingle-ply)	Built-up 3 ply & gravel	kg	$1.16 \times 10^{12}$	$4.76 \times 10^{11}$	$1.64 \times 10^{12}$	0	0		
Roof blocking	Wood	kg	$7.98 \times 10^{11}$	$8.70 \times 10^{10}$	$2.40 \times 10^{12}$	$1.52 \times 10^{12}$	0.65		
Electro welding net	Steel	kg	$1.17 \times 10^{12}$	$4.18 \times 10^{12}$	$6.97 \times 10^{12}$	$1.62 \times 10^{12}$	0.58		
Metal roof deck	Steel	kg	$1.17 \times 10^{12}$	$4.18 \times 10^{12}$	$6.97 \times 10^{12}$	$1.62 \times 10^{12}$	0.58		
Internal walls								0.60	0.04
Wall	Gypsum	kg	0	1.00	1.00	0	0		
Wall	CMU	kg	0	1.00	1.00	0	0		
Tape and finish	Fiberglass	kg	0	1.00	1.00	0	0		
Binder	Mortar	kg	0	1.00	$3.31 \times 10^{12}$	$3.31 \times 10^{12}$	1.00		
Tile	Ceramic	kg	$1.03 \times 10^{12}$	$2.03 \times 10^{12}$	$3.68 \times 10^{12}$	$6.20 \times 10^{11}$	0.38		
Pavements and coverings								0.99	0.01
Carpeting	Carpet	kg	0	1.00	1.00	0	0		
Resilient flooring	Linoleum	kg	0	1.00	1.00	0	0		
Ext. pavement	Red brick	kg	$1.89 \times 10^{11}$	$2.03 \times 10^{12}$	$3.68 \times 10^{12}$	$1.46 \times 10^{12}$	0.89		

Table 1. Cont.

Item	Specification	Unit	Specific Emergy (sej/kg)				RSI		% of RS
			RS	NR	Total (R + RS + NR)	R	R/(R + RS)		
							El.	Cp.	
Cove base	Rubber	kg	0	1.00	$7.22 \times 10^{12}$	$7.22 \times 10^{12}$	1.00		
Tread and riser	Rubber	kg	0	1.00	$7.22 \times 10^{12}$	$7.22 \times 10^{12}$	1.00		
Tile	Rubber	kg	0	1.00	$7.22 \times 10^{12}$	$7.22 \times 10^{12}$	1.00		
Walls and ceilings	Enamel	kg	0	1.00	1.00	0	0		
Walls and ceilings	Vinyl acrylic latex	kg	$5.29 \times 10^9$	$6.32 \times 10^{12}$	$6.33 \times 10^{12}$	0\	0		
Doors and windows								0.78	0.78
Door	Hollow metal	kg	0	1.00	1.00	0	0		
Door	Glass	kg	$6.22 \times 10^{12}$	$1.65 \times 10^{12}$	$7.87 \times 10^{12}$	0	0		
Door	Wood	kg	$7.98 \times 10^{11}$	$8.70 \times 10^{10}$	$2.40 \times 10^{12}$	$1.52 \times 10^{12}$	0.65		
Door frame	Hollow metal	kg	0	1.00	1.00	0	0		
Door frame	Wood	kg	$7.98 \times 10^{11}$	$8.70 \times 10^{10}$	$2.40 \times 10^{12}$	$1.52 \times 10^{12}$	0.65		
Door frame	Aluminum	kg	$4.70 \times 10^{10}$	$1.27 \times 10^{13}$	$2.13 \times 10^{13}$	$8.55 \times 10^{12}$	0.99		
Window	Glass	kg	$6.22 \times 10^{12}$	$1.6 \times 10^{12}$	$7.87 \times 10^{12}$	0	0		
Int. window casing frame	Wood	kg	$7.98 \times 10^{11}$	$8.70 \times 10^{10}$	$2.40 \times 10^{12}$	$1.52 \times 10^{12}$	0.65		
Ext. window casing frame	Aluminum	kg	$4.70 \times 10^{10}$	$1.27 \times 10^{13}$	$2.13 \times 10^{12}$	$8.55 \times 10^{12}$	0.99		
Int. window casings	Wood	kg	$7.98 \times 10^{11}$	$8.70 \times 10^{10}$	$2.40 \times 10^{12}$	$1.52 \times 10^{12}$	0.65		
Ext. window casings	Aluminum	kg	$4.70 \times 10^{10}$	$1.27 \times 10^{13}$	$2.13 \times 10^{13}$	$8.55 \times 10^{12}$	0.99		
Sheet-metal works								0.58	1.54
Tube	Steel	kg	$1.17 \times 10^{12}$	$4.18 \times 10^{12}$	$6.97 \times 10^{12}$	$1.62 \times 10^{12}$	0.58		
Structural tees	Steel	kg	$1.17 \times 10^{12}$	$4.18 \times 10^{12}$	$6.97 \times 10^{12}$	$1.62 \times 10^{12}$	0.58		
Channel	Steel	kg	$1.17 \times 10^{12}$	$4.18 \times 10^{12}$	$6.97 \times 10^{12}$	$1.62 \times 10^{12}$	0.58		
Angles	Steel	kg	$1.17 \times 10^{12}$	$4.18 \times 10^{12}$	$6.97 \times 10^{12}$	$1.62 \times 10^{12}$	0.58		
Plates, bent and flat	Steel	kg	$1.17 \times 10^{12}$	$4.18 \times 10^{12}$	$6.97 \times 10^{12}$	$1.62 \times 10^{12}$	0.58		
Drainage system								0.94	0.06
Standard PVC pipe	PVC	kg	0	1.00	$9.86 \times 10^{12}$	$9.86 \times 10^{12}$	1.00		
Junction box	Concrete	kg	$3.47 \times 10^{10}$	$1.41 \times 10^{12}$	$1.81 \times 10^{12}$	$3.65 \times 10^{11}$	0.91		
Reinforced concrete pipe	Concrete	kg	$3.47 \times 10^{10}$	$1.41 \times 10^{12}$	$1.81 \times 10^{12}$	$3.65 \times 10^{11}$	0.91		
Ductile iron pipe	Iron	kg	0	1.00	$6.97 \times 10^{12}$	$6.97 \times 10^{12}$	1.00		
Covering	Concrete	kg	$3.47 \times 10^{10}$	$1.41 \times 10^{12}$	$1.81 \times 10^{12}$	$3.65 \times 10^{11}$	0.91		

### 3.1.2. Step 2: Emergy Analysis of the Building Operation Process

In this step, energy use during building operation was assessed. Energy use data was obtained from the university's Physical Plant Division. For this building, steam is used primarily for space heating. Owing to an insignificant quantity of steam used, it was not included. Emergy for the operational phase is a product of the actual usage data of energy sources and their respective transformities. For this study, year 2010 energy data was used. Using the above data, total emergy flows including the Renewable Substitutability portions of the operational energy were calculated, Table 2.

**Table 2.** Emergy analysis of building operation.

Operational Energy Use	Unit (MBtu)	Emergy (sej)	Renewable Resource (R)	Renewable Substitutability Index (RSI)
<i>Electrical</i>	1446.5	$2.21 \times 10^{12}$	$3.35 \times 10^{10}$	0.11
<i>Chilled Water (Cooling)</i>	3864	$5.91 \times 10^{12}$	$8.94 \times 10^{10}$	0.11
<b>Total</b>	<b>5310.5</b>	<b><math>8.12 \times 10^{12}</math></b>	<b><math>1.23 \times 10^{11}</math></b>	<b>0.11</b>

### 3.1.3. Step 3: Emergy Analysis of the Building Maintenance Process

In this step, the depreciation of the stored emergy associated with building elements such as windows and doors was evaluated. For this paper, replacement of glass based on the building maintenance schedule was studied. Assuming a 100-year useful life for the building, the conventional float glass is replaced with traditional recycled float glass product every 30 years. As the Renewable Substitutability of the replacement product is larger than the ones that will be replaced, the overall Renewable Substitutability of the building is slated to improve, Table 3.

**Table 3.** Emergy analysis of building maintenance (using windows as an example).

Building Element	Lifetime (years)	Specific Emergy (sej/kg)		
		Non-Renewables (NR)	Total	Renewable (R)
Window	30	$1.65 \times 10^{12}$	$7.87 \times 10^{12}$	0
		$1.04 \times 10^{12}$	$7.69 \times 10^{12}$	0

### 3.1.4. Step 4: RSI Calculation

In this final step, the renewable emergy potential at the component-level and of the overall building is assessed to determine the respective RSI values, Table 4. It is to be noted that the RSI of a material remained constant relative to its specific emergy irrespective of its mass quantity. Alternatively put, a material retains its renewable emergy potential, which is derived based on its manufacturing process and does not alter when used in varied forms. This offers an opportunity to seek materials that have both higher Renewable Substitutability and are renewable (*i.e.*,  $RSI \rightarrow 1.0$ ), refer Table 1.

**Table 4.** Energy analysis of energy efficient measures.

Energy Efficient Measures (EEM)	Energy Use MBtu	Improvement (Saving) MBtu	%	Energy R (sej)	Improvement Energy (Saving) R (sej)	Renewable Resource (R) 10.6% Renew (sej)
<b>EEM1:</b> Change lighting power density—ASHRAE 90.1 space-by-space application	5214.1	96.4	0.018	$1.14 \times 10^{12}$	$2.11 \times 10^{10}$	$1.21 \times 10^{11}$
<b>EEM2:</b> Replace inefficient refrigerator—with Energy Star performer	5221.7	88.8	0.017	$1.14 \times 10^{12}$	$1.94 \times 10^{10}$	$1.21 \times 10^{12}$
<b>EEM3:</b> Modify temperature setpoint to 76F—SHRAE 90.1 as long as 80% of occupants are comfortable	5219.4	91.1	0.017	$1.14 \times 10^{12}$	$1.99 \times 10^{10}$	$1.21 \times 10^{11}$
<b>EEM4:</b> Install 20KW PV system—total area 2000 ft <sup>2</sup> on the roof	5221.1	89.4	0.017	$1.14 \times 10^{12}$	$1.95 \times 10^{10}$	$1.21 \times 10^{11}$
<b>EEM5:</b> Shorten Hours of Operation to 7 a.m.–9 p.m.—modify California Alternative Calculation Method (ACM) Manual from 6 a.m. to 10 p.m.	4633.7	676.8	0.127	$1.01 \times 10^{12}$	$1.48 \times 10^{11}$	$1.07 \times 10^{11}$
<b>EEM6:</b> Improve Energy Recovery Ventilation (ERV)—install ERV to handle additional outside air and install premium motor	5130.5	180.0	0.034	$1.12 \times 10^{12}$	$3.93 \times 10^{10}$	$1.19 \times 10^{11}$
<b>EEM7:</b> Reduce cooling capacity—specifically during weekends	4690.1	620.4	0.117	$1.02 \times 10^{12}$	$1.35 \times 10^{11}$	$1.09 \times 10^{11}$
<b>EEM8:</b> Repair lighting controls—classroom lights do not remain on during the night	5167.0	143.5	0.027	$1.13 \times 10^{12}$	$3.13 \times 10^{10}$	$1.20 \times 10^{11}$
<b>EEM9:</b> Install Variable Frequency Displays (VFD)—on both heating hot water pumps	5230.8	79.7	0.015	$1.14 \times 10^{12}$	$1.74 \times 10^{10}$	$1.21 \times 10^{11}$
<b>EEM10:</b> Provide higher temperature delta—in chilled water supply and return lines	5138.1	172.4	0.032	$1.12 \times 10^{12}$	$3.76 \times 10^{10}$	$1.19 \times 10^{11}$
<b>EEM11:</b> Install shut-off timers—in classroom to prevent 24 h idle load	3630.5	233.5	0.060	$7.93 \times 10^{11}$	$5.10 \times 10^{10}$	$8.40 \times 10^{10}$
<b>EEM12:</b> Repair lighting controls—classroom lights do not remain on during the night	5208.8	101.7	0.019	$1.14 \times 10^{12}$	$2.22 \times 10^{10}$	$1.21 \times 10^{11}$

### 3.2. Selection of Improvement Scenarios


RSI assessment methodology was used to calculate the RSI values, for both element- and component-levels. Using this data, several scenarios for improvement were evaluated from a holistic perspective in

order to maximize renewable resource use. For this paper, the operational and maintenance phases were assessed as discussed below.

### 3.2.1. Operational Phase

To reduce energy use in building operation, Energy Efficiency Measures (EEMs) are typically considered. Through evaluations of Renewable Substitutability potential of energy sources, an optimum solution that maximizes renewable resource use can be identified. Take, for example, the nine EEMs that were developed based on detailed energy audits and onsite building assessment [24].


Using the energy breakdown of the electricity and chilled water systems (steam was not included owing to insignificant quantities), each of the EEMs' equivalent energy flows including their renewable resource use were assessed, Table 4. In this study, 10.6% renewable electricity generation was the only renewable operational source for the building. Evaluating the RSI of all EEMs shows that EEM5 approaches 1.0 rapidly when compared with other EEMs, Figure 5. By calculating the ratio of the operational renewable energy use to total energy use, an RSI of 0.11 was calculated and remained a constant for all EEMs. However, if the renewable mix changes, these EEMs will not co-locate in the bisector, rather they will spread across the plot depicting their energy qualities.



**Figure 5.** RSI of energy efficient measures.

### 3.2.2. Maintenance Phase

By realizing the Renewable Substitutability of replacement during the maintenance phase, optimal solutions can be identified. Take, for example, the scenario that includes two replacement glazing, one with 10% renewables and another, 15%, Table 5, Figure 6. The second alternative possesses a higher RSI and is recommended for use as replacement glass.



**Figure 6.** Energy analysis of 10% and 15% renewable resource of replacement glass.

**Table 5.** Energy analysis of renewable substitutability of replacement glass (using 10% and 15% of the total energy required for manufacture as renewable resource).

Item	Energy (sej)			%	
	RS	NR	Total	RS	NR
Current Glazing Systems	$4.22 \times 10^{16}$	$1.12 \times 10^{16}$	$5.33 \times 10^{16}$	79%	21%
Replacement Glazing	$4.51 \times 10^{16}$	$7.05 \times 10^{15}$	$5.22 \times 10^{16}$	86%	14%
w/Renewable resources (10%)	$4.96 \times 10^{16}$	$2.53 \times 10^{15}$	$5.22 \times 10^{16}$	95%	5%
w/Renewable resources (15%)	$5.19 \times 10^{16}$	$2.79 \times 10^{15}$	$5.22 \times 10^{16}$	99%	1%

#### 4. Conclusions

This paper discussed the development of a Renewable Substitutability Index to maximize the incorporation of renewable resources in a building using emergy analysis. The central aspect of RSI is that it can be used to evaluate improvement strategies during the operation and maintenance phases of existing structures. A case study of an existing building in a university campus setting was used to demonstrate the application of RSI to attain maximum renewable resource investment. Using emergy (which accounts for energy qualities), the EEMs were assessed both for operational improvement and improvements in the maintenance phase. One of the limiting factors for the use of emergy evaluation in building assessments is the lack of a comprehensive database of building materials' specific emergy values with accurate data on renewable resource use. The configuration of raw materials, as well as, both the renewable and non-renewable portions (e.g., the renewable fraction of electricity) may differ regionally, as compared to national data. This may pose issues when calculating operational energy use and associated quantities of renewable resources. In addition, calculating the Renewable Substitutability of energy sources requires additional effort to provide location-specific values. For this purpose, authors Srinivasan, Campbell, and their team are currently developing an emergy database for

building components. Over sixty building components were identified and evaluated for their material compositions in terms of weights, which then are used with transformities to reconstruct the emergy content of a unit weight of the building component.

### Conflicts of Interest

Although EPA contributed to this article, the research presented was not performed by or funded by EPA and was not subject to EPA's quality system requirements. Consequently, the views, interpretations, and conclusions expressed in this article are solely those of the authors and do not necessarily reflect or represent EPA's views or policies.

### References

1. Guinee, J.B.; Heijungs, R.; Udo de Haes, H.A.; Huppes, G. Quantitative life cycle assessment of products: 2. Classification, valuation and improvement analysis. *J. Clean. Prod.* **1993**, *1*, 81–91.
2. Madu, C.N. *Handbook of Environmentally Conscious Manufacturing*; Kluwer Academic Publishers: Boston, MA, USA, 2001.
3. Zabala Bribián, I.; Aranda Usón, A.; Scarpellini, S. Life cycle assessment in buildings: State-of-the-art and simplified LCA methodology as a complement for building certification. *Build. Environ.* **2009**, *44*, 2510–2520.
4. Sartori, I.; Hestres, A.G. Energy use in the life cycle of conventional and low-energy buildings: A review article. *Energy Build.* **2007**, *39*, 249–257.
5. Ramesh, T.; Prakash, R.; Shukla, K.K. Life cycle energy analysis of buildings: An overview. *Energy Build.* **2010**, *42*, 1592–1600.
6. Asdrubali, F.; Baldassarri, C.; Fthenakis, V. Life cycle analysis in the construction sector: Guiding the optimization of conventional Italian buildings. *Energy Build.* **2013**, *64*, 73–89.
7. Zhang, Y.; Singh, S.; Bakshi, B.R. Accounting for ecosystem services in life cycle assessment, part I: A critical review. *Environ. Sci. Technol.* **2010**, *7*, 2232–2242.
8. Hau, J.L. Toward Environmentally Conscious Process Systems Engineering via Joint Thermodynamic Accounting of Industrial and Ecological Systems. Ph.D. Thesis, The Ohio State University, Columbus, OH, USA, May 2005.
9. Odum, H.T. *Environmental Accounting: Emergy and Environmental Decision Making*; Wiley: New York, NY, USA, 1996.
10. Brown, M.T.; Williams, S.B.; Tilley, D.R.; Ulgiati, S. Emergy Synthesis: Theory and Applications of the Emergy Methodology. In Proceedings of the First Biennial Emergy Analysis Research Conference, Gainesville, FL, USA, 2–4 September, 1999.
11. Buranakarn, V. Evaluation of Recycling and Reuse of Building Materials Using the Emergy Analysis Method. Ph.D. Thesis, University of Florida, Gainesville, FL, USA, 1998.
12. Meillaud, F.; Gay, J.B.; Brown, M.T. Evaluation of a building using the emergy method. *Sol. Energy* **2005**, *79*, 204–212.
13. Pulselli, R.M.; Simoncini, F.M.; Pulselli, S.; Bastianoni, S. Emergy analysis of building manufacturing, maintenance and use: Em-building indices to evaluate housing sustainability. *Energy Build.* **2007**, *39*, 620–628.

14. Price, J.; Tilley, D.R. Emergy Evaluation of Green Façade. In Proceedings of the Sixth Biennial Emergy Research Conference, Gainesville, FL, USA, 14–16 January 2010.
15. Srinivasan, R.S.; Ingwersen, W.; Trucco, C.; Ries, R.; Campbell, D. Comparing energy-based indicators used in life cycle assessment tools for buildings. *Build. Environ.* **2014**, *79*, 138–151.
16. Yi, H.; Srinivasan, R.S.; Braham, W.W. An integrated energy-emergy approach to building form optimization: Use of energypplus, emergy analysis, and taguchi-regression method. *Build. Environ.* **2015**, *84*, 89–104.
17. Pulselli, R.M.; Simoncini, F.M.; Marchettini, N. Energy and emergy based cost benefit evaluation of building envelopes relative to geographical location and climate. *Build. Environ.* **2009**, *44*, 920–928.
18. Srinivasan, R.S.; Braham, W.W.; Campbell, D.E.; Curcija, C.D. Re(de)fining net zero energy: Renewable emergy balance in environmental building design. *Build. Environ.* **2012**, *47*, 300–315.
19. Holling, C.S. The Resilience of Terrestrial Ecosystems: Local Surprise and Global Change. In *Sustainable Development in the Biosphere*; Clark, W.M., Munn, R.E., Eds.; Oxford University Press: Oxford, UK, 1986; pp. 292–320.
20. Odum, H.T. *Systems Ecology*; Wiley: New York, NY, USA, 1983.
21. Odum, H.T. *Ecological and General Systems*; Reprint of Systems Ecology; John Wiley: Hoboken, NJ, USA, 1983; University Press of Colorado: Niwot, CO, USA, 1994.
22. Bastianoni, S.; Pulselli, R.M.; Pulselli, F.M. Models of withdrawing renewable and non-renewable resources based on Odum's energy systems theory and Daly's quasi-sustainability principle. *Ecol. Model.* **2009**, *220*, 1926–1930.
23. Rinker Hall, University of Florida. *AIA/COTE Top Ten Green Projects*; Rinker Hall, University of Florida: Gainesville, FL, USA, 2004. Available online: <http://www2.aiaopten.org/hpb/overview.cfm?projectid=286> (accessed on 14 January 2014).
24. Stephany, D. The Value of Building Energy Audit Accuracy for Defining Effective Energy Efficient Measures. Master Thesis, University of Florida, Gainesville, FL, USA, August 2011.