

LA-UR-16-26762

Approved for public release; distribution is unlimited.

Title: NaI Measurements of Plutonium & Other Sources with the INL Coin

Author(s): Karpus, Peter Joseph

Intended for: NEOD Training Course, SNL Sept 2016

Issued: 2016-09-06

Disclaimer:

Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by the Los Alamos National Security, LLC for the National Nuclear Security Administration of the U.S. Department of Energy under contract DE-AC52-06NA25396. By approving this article, the publisher recognizes that the U.S. Government retains nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.

Nal Measurements of Plutonium & Other Sources with the INL Coin

Pete Karpus


Los Alamos National Laboratory

Introduction

- Several low-resolution (NaI) gamma-ray measurements were conducted with an IdentFINDER2 and the INL (dose ratio) Coin
- These slides summarize the effect of the INL Coin on gamma-ray spectra for ^{60}Co , ^{137}Cs , and plutonium.
- An investigation into gamma-ray scattering was also performed to explain a spectrum anomaly.

^{60}Co (bare) Baseline Spectrum

A bare 48 μCi ^{60}Co source was measured at ~ 30 cm from a NaI IdentifINDER 2. ID was ^{60}Co .




The two prominent gamma-ray peaks from ^{60}Co are at 1173 and 1332 keV. This is what we normally consider fairly high energy and the INL Coin will have only a slight effect on them.

^{60}Co + 1 INL Coin



A single INL Coin was placed between the ^{60}Co source and the IdentiFINDER 2.

ID was ^{60}Co .




Effect of INL Coin on ^{60}Co Peak Area

Here we compare the **peak area** of the 1332-keV peak of ^{60}Co as measured with the INL Coin to that without.





$$T = \frac{I}{I_0} = \frac{25023}{36256} \approx 0.69$$



This is called the 'transmission'. It describes the fraction of gammas *at a specific energy that* get through an attenuator.

^{60}Co + 2 INL Coins

Two INL Coins were placed between the ^{60}Co source and the IdentIFINDER 2. ID was ^{60}Co .




Transmission factors multiply, so since the transmission through 1 coin was 0.7, for two coins the transmission will be:


$$T = 0.7 \times 0.7 \approx 0.5$$

More on Transmission


Shielding of the same type and thickness, x




Let's say 1,000,000 gammas at same energy as above are incident upon an attenuator of the same type above but of twice the thickness.




'Bare' Super-Grade (SG) Plutonium



SG Pu + ^{137}Cs thru INL Coin



Bare Pu vs. Pu thru INL Coin



SG Pu thru 2" Pb brick


PeakEasy Ver. 4.86

Spectrum 661.Measurement.spe + Spectrum 655.Measurement.spe

Livetime: 299.0 sec


Deadtime: 0.33 %

Neutrons: 0.043 cps




^{137}Cs Scattering Study


To study the possibility that the 49-keV peak is just scattering of the 60-keV peak of ^{241}Am we use ^{137}Cs (it has a simpler spectrum than Pu) with the Pb brick on the table.



Why does scattered ^{137}Cs ID as U?



Eliminating the Scattered Peak



Summary

- Spectra recorded with and without the INL Coin illustrate how transmission plays a role in the dose-ratio factors written on the coin
 - Note: the coin references dose ratios, which are not exactly the same thing as peak area ratios.
- Plutonium was measured through the coin with and without the presence of other nuclides
- Nuclide ID results vary greatly.
- The issue of unwanted scattering reinforces documenting (through photos etc.) the measurement geometry and environment.